

Figures

Figure 1-1	Ultra Enterprise 3000 System	1-1
Figure 1-2	Ultra Enterprise 3000 Components	1-2
Figure 3-1	Filler Panel	3-3
Figure 3-2	CPU/Memory Board Simplified Block Diagram	3-5
Figure 3-3	Unlocking and Locking Quarter-Turn Access Slots	3-6
Figure 3-4	CPU/Memory Board	3-7
Figure 3-5	Board Slot Locations	3-8
Figure 3-6	UltraSPARC Module Connector Detail	3-11
Figure 3-7	UltraSPARC Module Connector Detail	3-12
Figure 3-8	UltraSPARC Module Removal and Replacement	3-13
Figure 3-9	Tightening Compression Bar Screws	3-15
Figure 3-10	Layout of CPU/Memory Board	3-17
Figure 3-11	Ejecting a SIMM	3-18
Figure 3-12	Orienting and Installing a SIMM	3-20
Figure 4-1	Filler Panel	4-3
Figure 4-2	SCSI Terminator	4-3

Figure 4-3	SBus I/O Board Components Locations	4-6
Figure 4-4	Graphics I/O Board Components Locations.	4-7
Figure 4-5	SBus I/O Board Simplified Block Diagram	4-8
Figure 4-6	Graphics I/O Board Simplified Block Diagram	4-9
Figure 4-7	Unlocking and Locking Quarter-Turn Access Slots	4-10
Figure 4-8	I/O Board (Graphics)	4-11
Figure 4-9	Board Removal and Replacement.	4-12
Figure 4-10	I/O Board SBus Card Locations	4-15
Figure 4-11	Locking and Unlocking Standoffs.	4-16
Figure 4-12	Removing or Installing an SBus Card	4-17
Figure 4-13	SBus Card Rear Panel with Adapter.	4-19
Figure 4-14	Card Retainer	4-19
Figure 4-15	DSBE/S SBus Card	4-20
Figure 4-16	FSBE/S SBus Card.	4-21
Figure 4-17	Disabling and Enabling the Link Integrity Test	4-21
Figure 4-18	Graphics (UPA) Card Connector Location	4-23
Figure 4-19	Removing or Installing a Graphics (UPA Card)	4-24
Figure 4-20	I/O Board Fibre Card Connector Locations	4-27
Figure 4-21	Removing or Installing A Fibre Card	4-28
Figure 5-1	Clock Board	5-3
Figure 5-2	Clock Board Simplified Block Diagram	5-4
Figure 5-3	Clock Board Location	5-7
Figure 6-1	Peripheral Power Supply/AC Input	6-4
Figure 6-2	Peripheral Power Supply	6-4
Figure 6-3	Unlocking and Locking Quarter-turn Access Slots	6-5

Figure 6-4	Replacing the Peripheral Power Supply/AC Input	6-6
Figure 6-5	PCM	6-8
Figure 6-6	Unlocking and Locking Quarter-turn Access Slots	6-11
Figure 6-7	Replacing a PCM in the Enterprise 3000 System	6-12
Figure 7-1	Internal SCSI and Storage Device Locations	7-2
Figure 7-2	Front Bezel	7-3
Figure 7-3	SCSI Tray Removal and Replacement	7-4
Figure 7-4	Disk Drive Access	7-6
Figure 7-5	Disk Drive Slot Locations	7-7
Figure 7-6	Disk Drive with Retainer Unlatched and Extended	7-8
Figure 8-1	Details of the Clock Board	8-2
Figure 8-2	Front Panel LEDs	8-3
Figure 8-3	Slot Numbers for the Card Cage	8-7
Figure 9-1	Diagnosing AC/DC Power Problems	9-2
Figure 9-2	Diagnosing Operating System Problems	9-3
Figure 9-3	Replacing I/O Interface	9-4
Figure 9-4	Replacing I/O Interface	9-5
Figure 9-5	Diagnosing Disk Drive Problems	9-6
Figure 9-6	Diagnosing Power Supply Problems	9-7
Figure 9-7	Diagnosing a Defective Clock Board	9-8
Figure 11-1	Keypad Standby Position	11-2
Figure 11-2	AC Power Switch and Power Receptacle	11-3
Figure 11-3	System Reset Switch on Clock Board	11-6
Figure 11-4	Front Panel Status LEDs	11-7
Figure 12-1	Removing the Front Bezel	12-2

Figure 12-2	Removing the SCSI Tray	12-3
Figure B-1	4-Slot Enterprise 3000 Cabinet	B-2
Figure B-2	Bus Structure	B-3
Figure B-3	CPU/Memory Board	B-4
Figure B-4	SIMM Slot Locations	B-6
Figure B-5	SBus I/O Board	B-7
Figure B-6	Graphics I/O Board	B-8
Figure B-7	Peripheral Power Supply/AC	B-9
Figure B-8	Locations of the PPS/AC, PPS, and Clock Board	B-10
Figure B-9	Clock Board	B-11
Figure D-1	Board Slots and Power Supply Locations	D-2
Figure D-2	Disk Drive Slot Numbers	D-6
Figure E-1	Removing the Fan Tray Assembly	E-2
Figure E-2	Unlocking and Locking Quarter-Turn Access Slots	E-4
Figure E-3	Removing the Auxiliary Fan Tray	E-4
Figure E-4	Removing the Side Panel	E-7
Figure E-5	Removing the Front Bezel	E-8
Figure E-6	Removing the SCSI Tray	E-9
Figure E-7	Cable Connectors on the Centerplane	E-11
Figure E-8	Key Switch PWB Centerplane Cable	E-12
Figure E-9	Locking Tabs on the LED Board	E-13
Figure E-10	Removing the Key Switch Lock Cable Assembly	E-15
Figure E-11	Enterprise 3000 System Without the Front Chassis	E-19
Figure E-12	Centerplane Guide Pins	E-21
Figure G-1	CPU/Memory Board Connector Locations	G-2

Figure G-2	CPU/Memory Board Centerplane Connector Location	G-3
Figure G-3	Centerplane Connector Detail	G-3
Figure G-4	CPU Module 0 Connector (144 Pin) Location	G-4
Figure G-5	CPU Module 1 Connector (144 Pin) Location	G-4
Figure G-6	CPU Module 0 Connector (288 Pin) Location	G-5
Figure G-7	CPU Module 1 Connector (288 Pin) Location	G-5
Figure G-8	SBus I/O Board Connector Locations	G-6
Figure G-9	Graphics I/O Board Connector Locations	G-6
Figure G-10	I/O Board SBus 0 Connector Locations	G-7
Figure G-11	I/O Board SBus 1 Connector Location	G-7
Figure G-12	I/O Board SBus 2 Connector Locations	G-8
Figure G-13	Graphics I/O Board UPA Connector Location	G-8
Figure G-14	I/O Board Ethernet Connector Locations	G-9
Figure G-15	I/O Board MII Connector Locations	G-9
Figure G-16	I/O Board Fiber 0 Interface Connector Locations	G-10
Figure G-17	I/O Board Fiber 1 Interface Connector Locations	G-10
Figure G-18	I/O Board SCSI Connector Locations	G-11
Figure G-19	Clock Board Connector Locations	G-11
Figure G-20	Clock Board Centerplane Connector Location	G-12
Figure G-21	Clock Board Serial Port Connectors Locations	G-12
Figure G-22	Serial Port A and B Connector Pinouts	G-13
Figure G-23	Clock Board Keyboard/Mouse Connector Location	G-13
Figure G-24	Keyboard and Mouse Connector Pinouts	G-14

