

Contents

Preface xix

1. Overview and Specifications 1

Expansion Unit Overview 1

Architecture 2

Specifications 4

Physical Dimensions 4

Power Supply 4

Environmental Specifications 4

Release Information 5

Netra t System Information 5

SunFastEthernet PCI Adapter Issues 5

Configuring `/etc/hostname.hmeN` Host Files 6

Other PCI User Card Issues 6

2. Installing the Netra xt 600 Expansion Unit 7

Preparing for Installation 8

Installation Precautions 8

Tools Required 8

▼ To Prepare for Installation 9

Unpacking the Expansion Unit and the Host Interface Card	9
Installing the Host Interface Card in the Host System	11
▼ To Install the Host Interface Card	11
Installing User Cards Into the Expansion Unit	12
▼ To Install a User Card	12
Installing the Expansion Unit	14
Planning the Installation	14
Installing the Expansion Unit in a Rack Mount Cabinet	15
▼ To Install the Expansion Unit in a 19-inch Rack Mount Cabinet	16
▼ To Install the Expansion Unit in a 23-inch, 24-inch, or a 600-mm Rack Mount Cabinet	22
Connecting the Host System to the Expansion Unit	26
▼ To Install the Connector Cable	26
Connecting the Expansion Unit Power Cables	27
▼ To Connect the Power Cable	27
Powering On the Expansion Unit	28
▼ To Power On the Expansion Unit	28
Powering Down the Expansion Unit	29
▼ To Power Down the Expansion Unit	29
3. Locating PCI Devices and Troubleshooting	31
Locating PCI Devices Installed in the Expansion Unit	32
Logical and Physical Device Numbers	33
Troubleshooting	35
▼ To Isolate Problems With the Expansion Unit	35
Creating <code>/etc/hostname.hmeN</code> Host Files for SunFastEthernet PCI Adapters	36
▼ To Configure the FastEthernet Host Files	36

A. Accessing and Replacing the Field Replaceable Units	39
Ordering Replaceable Components	40
Replacing the Air Filter	41
▼ To Replace the Air Filter	41
Extending or Removing the Expansion Unit from a Rack	42
▼ To Extend or Remove the Expansion Unit from a 19-Inch Rack	42
▼ To Remove the Expansion Unit from a 23-inch, 24-inch or 600-mm Rack	44
Installing the Expansion Unit in a Rack Mount Cabinet	46
▼ To Install the Expansion Unit in a 19-Inch Rack Mount Cabinet	46
▼ To Install the Expansion Unit in a 23-inch, 24-inch, or 600-mm Rack Mount Cabinet	49
Removing and Replacing PCI User Cards	50
▼ To Remove the Top Access Cover and the Restraining Bar	50
▼ To Remove a PCI User Card	53
▼ To Replace a PCI User Card	54
▼ To Replace the Restraining Bar and the Top Access Cover	55
Removing and Replacing the Expansion Unit	57
▼ To Remove the Expansion Unit	57
▼ To Replace the Expansion Unit	59
Index	63

