

# Contents

---

Preface .....	v
<b>1. Preparing for Installation .....</b>	<b>1-1</b>
1.1 Features .....	1-1
1.2 Requirements for Using the SBus Adapter .....	1-2
<b>2. Installing the Adapter .....</b>	<b>2-1</b>
2.1 Performing the Installation .....	2-1
2.2 Verifying the Installation .....	2-2
2.3 Watching Network Activity .....	2-3
<b>3. Installing SunSwift SBus     Adapter Software     On Solaris 2.4 and 2.5 Systems .....</b>	<b>3-1</b>
3.1 Preparing for Software Installation .....	3-2
3.2 Net-Install of Solaris 2.4 Over the hme Interface .....	3-3
3.3 Host File Configuration .....	3-4
3.4 Caution: Package Dependency .....	3-5
3.5 Booting .....	3-6

---

3.5.1	Booting From the Network Using Solaris 2.5 . . . . .	3-6
3.5.2	Diskless Client Booting for Solaris 2.4 . . . . .	3-7
3.5.3	Booting From the Network Using Solaris 2.4 . . . . .	3-8
3.6	Post-Installation Procedures (Optional) . . . . .	3-10
3.6.1	Using Hubs That Do Not Send Link Pulses. . . . .	3-10
3.6.2	Configuring Driver Parameters. . . . .	3-11
3.6.3	Increasing 100BASE-T Performance . . . . .	3-11
3.6.4	Forcing Network Speed Between 10 Mbps and 100 Mbps . . . . .	3-12
3.6.5	Auto-Negotiation . . . . .	3-13
<b>A.</b>	<b>Running Diagnostics for Solaris 2.4 . . . . .</b>	<b>A-1</b>
<b>B.</b>	<b>Interface Signals . . . . .</b>	<b>B-1</b>
<b>C.</b>	<b>Specifications. . . . .</b>	<b>C-1</b>